

## Infant Change Table

The most common workplace injuries in childcare centres are caused by frequent lifting of children. To address this issue, the Infant Change Table has been manufactured with a minimum height of 440 mm to allow toddlers to enter and exit with minimal assistance. Electric height adjustment up to 840 mm facilitates carers of varying heights working at their optimum level.

The Infant Change Table has the option of a cordless handset and removable battery pack for maximum safety in the childcare environment. Falls can be prevented by installing a safety strap or high cot sides.



### Specifications

Product specifications	
Product weight capacity	100kg
Product length	800mm
Product width	500mm
Product weight	100kg
Lifting Range	440 – 840mm
Control options	Handset or cordless remote
Upholstery	High quality medical grade vinyl over 38mm foam
Frame	Powdercoated steel
Warranty	5 years excluding upholstery



Change table in raised position



Change table with padded safety strap



Change table with castors fitted